



SPECTRE STARTER KIT

Starter Kit content		SPECTRE INDUSTRY	SPECTRE EXTREM
Part numbers – 865 to 868 MHz		STKIT-SLIW44	STKIT-SLEW44
Part numbers - 902 to 928 MHz		STKIT-SLIW54	STKIT-SLEW54
SLI 1 SPECTRE Industry reader + 1 SPECTRE antenna + 1 USB C / USB A cable + 1 USB key with SESPRO software + documentation		✓	
SLE 1 SPECTRE Extrem reader + 1 SPECTRE antenna + 1 USB C / USB A cable + 1 USB key with SESPRO software + documentation			✓
1 Wall + pole mounting kit		✓	✓
1 Ethernet cable – 2m		✓	
1 Power supply (24 VDC) with screwable plug jack connector		✓	
1 M12 A-coded straight plug connector			✓
1 M12 A-coded angle plug connector		✓	✓
1 M12 X-coded straight plug connector to RJ45 - 2 m			✓
1 UHF metal tag - IronTag® Aero		✓	✓
1 UHF metal tag - IronTag® 360		✓	✓
1 UHF metal tag - PuceTag		✓	✓
1 UHF label - Customized ETA v2		✓	✓
1 UHF label – White ETA v2		✓	✓
1 Small UHF label - White ThinTag mini		✓	✓

Flyer_Starter_Kit_SPECTRE_EN_v1.0

Headquarters / EMEA

13850 Gréasque, France
Tel.: +33 (0)4 42 12 60 60

PARIS-IDF Office

92290 Châtenay-Malabry, France
Tel.: +33 (0)1 43 50 11 43

STid UK Ltd.

Gallows Hill, Warwick CV34 6UW, UK
Tel.: +44 (0) 192 621 7884

NORTH AMERICA Office

Irving, Texas 75063-2670, USA
Tel.: +1 469 524 3442

LATINO AMERICA Office

San Rafael 06470 CDMX, México
Tel.: +521 (55) 5256 4706

info@stid.com

www.stid-industry.com